1/4ñ SIZE CLASSIC ATOMIZERS


BODY TIPES AND OPTIONS


MW

COMPLETE CODE

To obtain the complete code for an atomizer it is necessary to use the set-up code you have choosen from the performance table and complete it with the code for body and options as follows:

- ò Replace the first two letters in the set-up code (SU) with the code for standard body (MW).
- ò Add the code for the material you require.
- ò Add the code for the required options, if any, and the thread type code.





AA = Air inlet 1/4ñ female LI = Liquid inlet 1/4ñ female